

## Fitting Instructions for a Centrepiece

- 1. Holding the centrepiece in the required position, mark around the outside edge on to the ceiling using a pencil.*
- 2. Within the pencil line, rough the ceiling surface area with a utility knife, and then probe ceiling area with a nail (or something similar) to find the position of the ceiling joists. Mark these on the ceiling & the Rose.*
- 3. Pre-drill the centrepiece to accept the fitting screws at a strong point in the centrepiece.*
- 4. Paint a thinned PVA (5 parts water 1 PVA) on the ceiling and back side of the centrepiece area, you can now use 1 of 2 types of adhesives: gyproc cornice adhesive or tile adhesive.*
- 5. If a light fitting is required through the centrepiece, drill a hole for the wires and thread them through when fitting the centrepiece. When fixing the light fitting make sure that it is fastened securely to the ceiling joist and not to the centrepiece.*
- 6. Spread the Gyproc or tile adhesive on to the back surface of the pre-drilled centrepiece and locate into position on the ceiling. Fix on to the ceiling using rust proof screws. (Never rely on the adhesive only to fix a centrepiece)*
- 7. Make good edges and any pre-drilled holes with the adhesive filler.*